

# SIERRA TEL REMOTE CONTROL GUIDE

Contact us at 559-683-4611, 209-966-3636, or 877-658-4611.  
Visit us online at [www.SierraTel.com](http://www.SierraTel.com).



## SHORTCUT BUTTONS



RED - Current program info  
GREEN - Help  
YELLOW - Channel guide  
BLUE - Previous menu

**HOME** - This remote does not have a Home button. If you get an error message that refers to it, unplug your set-top device for 10 seconds and plug back in to reset.

Note: Some button functionality (ex: DVR) may not be available dependent upon subscribed services. \*These buttons will control the TV functions in both TV mode and STB mode, once configured to operate your TV set.

# SIERRA TEL WHOLE-HOME DVR

## QUICK START GUIDE

### RECORD LIVE TV

Record the program you are watching by pressing the **RECORD** button. From the Program Playing screen press **OK** on **RECORD**. The program will be recorded until it is scheduled to finish. To manually stop the recording before it is scheduled to finish, press **i (INFO)** and select **STOP RECORDING**.

### RECORD FROM GUIDE

Use the **GUIDE** to navigate to the program you want to **RECORD** and press the **RECORD** button.

### VIEW A RECORDED PROGRAM

Press the **My DVR** button on your remote control to launch the DVR menu. Navigate to the program you want to view. Press **OK**, arrow over to **START**, press **OK**.

- Press **FAST FORWARD** to advance the program.
- Press **FAST FORWARD** repeatedly to change the fast forward speed by 2, 4, 8, or 16 times.
- **RAPID FAST FORWARD** will advance the program 30 seconds.
- Press **REWIND** to reverse the program.
- Press **REWIND** repeatedly to change the rewind speed by 2, 4, 8, or 16 times.
- **RAPID REWIND** will rewind the program 60 seconds.

Complete User Guide available at [www.sierratel.net/home/stv](http://www.sierratel.net/home/stv) for instructions on how to **CREATE A SERIES RECORDING**, **DELETE A SHOW**, and **CONTROL LIVE TV**.

**NOTE:** The DVR is not intended to be a long-term storage device. Keep in mind that once you reach your recording maximum, older shows will automatically be deleted, if not protected.



559-683-4611 • 209-966-3636 • 877-658-4611  
[www.SierraTel.com](http://www.SierraTel.com)